

## FlexSQUARE / LED Double Flash Beacon 853

# **LED Double Flash Beacon BWM 48VAC GN**



Part No.: 853.210.66



MECHANICAL DATA	
Length	85 mm
Width	85 mm
Height	72 mm
Materials	PC PP-GF
Dome colour	Green
Housing colour	Black
Protection category	IP66 IP67
Connection	Screw terminals
cross-sectional area maximum	1,50mm <sup>2</sup> / 16AWG
Cable entry	Membrane grommet
Cable entry minimum	d = 1 mm d = 6 mm
Cable entry maximum	d = 12 mm d = 9 mm
Type of fixing	Base mounting Wall mounting
Working temperature minimum	-25°C
Working temperature maximum	+50°C
Weight with packaging	189 g
Product weight	159 g

ELECTRICAL DATA		
Operating voltage	48V	
Operating voltage type	AC	
Operating voltage frequency	50Hz	
Operating voltage tolerance	+/- 10%	
Rated operational voltage	48 VAC	
Rated operational current	95 mA	
Rated inrush current	2.000 mA	
Protection class	Protection class 2	
Pollution degree	3	

OPTICAL DATA		
Light source	LED	
Light colour	Green	
Optical signal image	Double flash	
Flash frequency	1 Hz	
Service life optical	50,000 h maximum	

For additional installation and mounting information, refer to the appropriate user guide at www.werma.com. This printed copy is for information only and is subject to alteration.



#### FlexSQUARE / LED Double Flash Beacon 853

## **LED Double Flash Beacon BWM 48VAC GN**


APPROVAL DATA	
Conforms with CE	Yes
Conforms with RoHS directive	Yes
WEEE	Yes
Conforms with ATEX-directive	No
Conforms with CCC	No
Conforms with UL	No
Conforms with FCC	No
Conforms with IC	No
EAC certificate available	Yes
Conforms with UKCA (Importer)	Yes (WERMA (UK) Ltd.)
Conforms with AS-I	No
ICAO Certification	No
Conforms with DNV	No
Conforms with RoHS CN	No
Conforms with VdS	No

For additional installation and mounting information, refer to the appropriate user guide at www.werma.com. This printed copy is for information only and is subject to alteration.



FlexSQUARE / LED Double Flash Beacon 853

## **LED Double Flash Beacon BWM 48VAC GN**



For additional installation and mounting information, refer to the appropriate user guide at www.werma.com. This printed copy is for information only and is subject to alteration.