Maxi free-standing Beacons / EvoSIGNAL Maxi TwinFLASH 115-230VAC RD



ļ

| Part No.: | 262.120.60 | |
|-----------------------------|--------------------|------------------------------|
| Series: | EvoSIGNAL | |
| MECHANI | CAL DATA | |
| Height | | 173 mm |
| Diameter | | 120 mm |
| Materials | | PC PC/ABS |
| Dome colour | | Red |
| Housing co | lour | Grey |
| Protection | category | IP66 |
| Connectior | 1 | Push-in terminal |
| cross-secti | onal area minimum | 0,25mm² / 24AWG |
| cross-secti | onal area maximum | 1,50mm² / 16AWG |
| Type of fixi | ing | Adapter required |
| Working te | mperature minimum | -30°C |
| Working temperature maximum | | +60°C |
| Weight with packaging | | 500 g |
| Product weight | | 350 g |
| ELECTRIC | AL DATA | |
| Operating voltage | | 115-230V |
| Operating v | voltage type | AC |
| Operating voltage frequency | | 50Hz at 230V 60Hz at 115V |
| Operating | voltage tolerance | +/- 10% |
| Rated oper | ational voltage | 230 VAC |
| Rated oper | ational current | 165 mA |
| Rated inrush current | | <6000 mA |
| Protection class | | Protection class 2 |
| Pollution degree | | 3 |
| Overvoltage category | | II |
| Isolation vo | oltage | Ui = 250V; Uimp = 2.500V |
| OPTICAL I | DATA | |
| Light source | | LED |
| Light colou | r | Red |
| Optical signal image | | EVS Flash TwinFlash |
| Flash frequency | | 1 Hz |
| Service life optical | | 50,000 h minimum |
| | ause Duration [ms] | 480N, 960FF, 480N, 8200FF |
| - 1 | | |

For additional installation and mounting information, refer to the appropriate user guide at www.werma.com. This printed copy is for information only and is subject to alteration.


ļ

Maxi free-standing Beacons / EvoSIGNAL Maxi TwinFLASH 115-230VAC RD

| APPROVAL DATA | |
|---------------|--|
|---------------|--|

| es es es |
|----------------------|
| es |
| |
| |
| 0 |
| es |
| ULus |
| ype 12 |
| 0 |
| 0 |
| es |
| es (WERMA (UK) Ltd.) |
| 0 |
| 0 |
| 0 |
| 0 |
| 0 |
| 34 |
| |

DRAWING



For additional installation and mounting information, refer to the appropriate user guide at www.werma.com. This printed copy is for information only and is subject to alteration.